



CAT TAILER™ User Manual/Manuel Utilisateur

North American Version

Setup Guide

1. Compatible devices include the iPhone 4S & later and Android 4.3 devices and later with Bluetooth 4.0+.
2. Download the CAT TAILER companion app. Search the App store or Google Play for CAT TAILER.
3. Turn Bluetooth ON.
Make sure your phone's Bluetooth is turned ON and open the CAT TAILER app.
4. Notification and Location
Please accept the requested app permissions.
5. Select the scan button
6. Name your CAT TAILER
Make sure your CAT TAILER is nearby your device. Select and name each of your CAT TAILER devices.

Optionally add a photo of your cat and select notification options.
7. For more information go to: www.cattailer.com


How to find your pet with CAT TAILER

CAT TAILER broadcasts its homing beacon roughly once a second. The companion smartphone application receives this signal and will locate your CAT TAILER if it is within range. The smartphone display reports the distance to your pet. Since the signal is only received a maximum of once a second, you may have to wait several seconds for the application to display the distance to your pet. Similarly, as you walk the distance measurement will update every second or so. For these reasons a slow pace is best. Make sure to keep your smartphone awake while you look for your pet. The CAT TAILER application will not function while the phone is asleep.

Generally, start by walking toward your pet's favorite haunts. The application will report that you are closer to your pet. For instance, if you turn around and suddenly the distance is shorter, then that is the direction to go. Keep in mind that buildings, hills and even people in the line of sight to the CAT TAILER change the accuracy of the distance measurement. Once the application locates your pet use the distance information to guide you to your pet.

Always Remember

- Pay attention to your surroundings while using the CAT TAILER application.
- Walk completely around your own home and out buildings, then proceed to look around your community.



Guide d'Installation

1. Les périphériques compatibles comprennent les appareils iPhone 4S et modèles plus récents et Android 4.3 et modèles plus récents avec Bluetooth 4.0+.
2. Téléchargez l'application compagnon CAT TAILER. Recherchez l'App Store ou Google Play pour CAT TAILER.
3. Activez Bluetooth. Assurez-vous que le Bluetooth de votre téléphone est activé et ouvrez l'application CAT TAILER.
4. Notification et Emplacement
Veuillez accepter les autorisations de l'application demandée.
5. Sélectionnez le bouton de numérisation
6. Nommez votre CAT TAILER Assurez-vous que votre CAT TAILER se trouve à proximité de votre appareil. Sélectionnez et nommez chacun de vos périphériques CAT TAILER.

Vous pouvez également ajouter une photo de votre chat et sélectionner les options de notification.
7. Pour plus d'informations, visitez: www.cattailer.com


Comment trouver votre animal de compagnie avec CAT TAILER

CAT TAILER diffuse sa balise environ une fois par seconde. L'application de téléphone portable compagnon reçoit ce signal et localise votre CAT TAILER s'il se trouve dans la portée. L'écran de votre téléphone intelligent indique la distance de votre animal de compagnie. Étant donné que le signal n'est reçu qu'un maximum d'une fois par seconde, vous devrez peut-être attendre plusieurs secondes pour que l'application affiche la distance de votre animal de compagnie. De même, au cours de la marche, la mesure de la distance se mettra à jour environ chaque seconde. Pour ces raisons, un rythme lent est meilleur. Assurez-vous de garder votre téléphone intelligent éveillé pendant que vous cherchez votre animal de compagnie. L'application CAT TAILER ne fonctionnera pas lorsque le téléphone est veille.

Généralement, commencez par marcher vers les lieux préférés de votre animal de compagnie. L'application indiquera que vous êtes plus proche de votre animal de compagnie. Par exemple, si vous vous tournez et que soudain, la distance est plus courte, alors c'est la direction à suivre. Gardez à l'esprit que les bâtiments, les collines et même les personnes dans la ligne de visée à l'Adaptateur Cat changent la précision de la mesure de la distance. Une fois que l'application localise votre animal, utilisez les informations de distance pour vous guider dans votre animal de compagnie.

Toujours se rappeler

- Faites attention à votre environnement lors de l'utilisation de l'application CAT TAILER.
- Marchez complètement autour de votre maison et de vos bâtiments, puis passez en revue votre quartier.



Regulatory Statements

Industry Canada

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IC: 22964-CT105

Model: CT105

CAN ICES-3 (B)/NMB-3(B)

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID: 2AK42CT105

Disclaimer of Warranties & Limitation of Liability

Ambystoma Labs Inc. reserves the right to make changes without further notice to any products herein. Ambystoma Labs Inc. makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Ambystoma Labs Inc. assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters can and do vary in different applications. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. Ambystoma Labs Inc. does not convey any license under its patent rights nor the rights of others. Ambystoma Labs Inc. products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Ambystoma Labs Inc. product could create a situation where personal injury or death may occur. Should Buyer purchase or use Ambystoma Labs Inc. products for any such unintended or unauthorized application, Buyer shall indemnify and hold Ambystoma Labs Inc. and its offices, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Ambystoma Labs Inc. was negligent regarding the design or manufacture of the part

Ambystoma Labs Inc. endeavors to ensure that the information in this document is correct and fairly stated but does not accept liability for any error or omission. The development of Ambystoma Labs Inc. products and services is continuous and published information may not be up to date. It is important to check the current position with Ambystoma Labs Inc.

CAT TAILER, the PARTIAL BLACK CAT LOGO, and AMBYSTOMA LABS are trademarks of Ambystoma Labs Inc. All other trademarks belong to their respective owners and are recognized and acknowledged.

Changing the Battery

The battery in your CAT TAILER will last 6 months or more. Once it has become depleted, the light will change from flashing green to flashing red. At this point you should replace the battery within a week. The battery is a standard CR1632 lithium coin cell and is available at most stores worldwide.

1. Begin by removing the key ring from the loop on CAT TAILER.
2. Grasp the front and back of CAT TAILER and rotate counter clockwise one quarter turn and remove the front cover.
3. Grasp the edges of the circuit board and pull it free of the plastic case.



4. Use a non-metallic tool to push the battery out of its holder. In this photo a chopstick is used.



5. Insert the new battery. Note the "+" side or flat side is up. Verify you have correctly inserted the battery by waiting to see the green light flash.



6. When re-inserting the circuit board into the plastic case, note that it can only be inserted one way.

7. Place the front cover back on and rotate clockwise until the two halves of the loop line up.

Battery Precautions

- Use only CR1632 batteries.
- Install only new batteries in your CAT TAILER.
- Failure to insert the battery in the correct polarity as indicated on the product may shorten the life of the battery or cause the battery to leak.
- Do not dispose of batteries in fire.
- Batteries should be recycled or disposed of per your local regulations.

IMPORTANT SAFETY WARNINGS

CAT TAILER is only designed for attachment to your pet cat's collar. It is should never be worn by or attached to adults or children.

CHOKING HAZARD - CAT TAILER is not a toy. Keep it out of reach of young children. Do not use it as a toy with your pet.

DO NOT put CAT TAILER in your mouth at any time.

WATER RESISTANCE - CAT TAILER is waterproof and designed to survive dunking in a water bowl and even the most bold adventures of an aquatic loving cat. It is not designed for continuous submersion in water.

Always pay attention to your surroundings when using the CAT TAILER companion application to find your pet. Do not become distracted while using the CAT TAILER application and be attentive to unforeseen obstacles and vehicular traffic.

Warranty

CAT TAILER is covered under a warranty for a full year from the date of purchase. Learn more at cattailer.com/warranty.

Ambystoma Labs Inc. does not warrant that the operation of the Product will be uninterrupted or error-free. Ambystoma Labs Inc. Is not responsible for damage arising from failure to follow instructions relating to the Ambystoma Labs Products' use.

Limitation of Damages. EXCEPT TO THE EXTENT PROHIBITED BY LAW, AMBYSTOMA LABS INC. SHALL NOT BE LIABLE FOR ANY INCIDENTAL, INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF EXPRESS OR IMPLIED WARRANTY OR CONDITION, OR UNDER ANY OTHER LEGAL THEORY.

Changer la Batterie

La batterie de votre CAT TAILER durera 6 mois ou plus. Une fois qu'elle est épuisée, la lumière passera du vert clignotant au rouge clignotant. À ce stade, vous devez remplacer la batterie en moins d'une semaine. La batterie est une pile au lithium CR1632 standard et est disponible dans la plupart des magasins à travers le monde.

1. Commencez par enlever le porte-clés de la boucle sur le CAT TAILER.
2. Tirez l'avant et l'arrière du CAT TAILER et tournez dans le sens inverse des aiguilles d'une montre un quart de tour et retirez le capot avant.
3. Saisissez les bords de la carte de circuit imprimé et retirez-le de l'étui en plastique.



4. Utilisez un outil non métallique pour retirer la batterie de son support. Dans cette photo, on utilise un baguette.



5. Insérez la nouvelle batterie. Notez que le côté "+" ou le côté plat est vers le haut. Vérifiez que vous avez correctement inséré la batterie en attendant de voir lumière verte clignoter.



6. Lors de la réinsertion de la carte de circuit imprimé dans le boîtier en plastique, notez qu'elle ne peut être insérée que dans un sens.

7. Remplacez le capot avant de le tournez dans le sens des aiguilles d'une montre jusqu'à ce que les deux moitiés de la boucle s'allument.

Précautions pour la batterie

- Utilisez uniquement des piles CR1632.
- Installez uniquement de nouvelles piles dans votre CAT TAILER.
- Le fait de ne pas insérer la batterie dans la polarité correcte comme indiqué sur le produit peut raccourcir la durée de vie de la batterie ou provoquer une fuite de la batterie.
- Ne jetez pas les piles dans le feu.
- Les batteries doivent être recyclées ou éliminées conformément à la réglementation locale.

AVERTISSEMENTS DE SÉCURITÉ IMPORTANTS

CAT TAILER est uniquement conçu pour être attaché au collier de votre chat. Il ne doit jamais être porté ou attaché à des adultes ou des enfants.

RISQUE D'ÉTRANGLEMENT - CAT TAILER n'est pas un jouet. Gardez-le hors de portée des jeunes enfants. Ne l'utilisez pas comme un jouet avec votre animal de compagnie.

NE JAMAIS METTRE CAT TAILER dans votre bouche.

RÉSISTANCE À L'EAU - CAT TAILER est imperméable à l'eau et conçu pour survivre au trempage dans un bol d'eau et même aux aventures les plus audacieuses d'un chat aquatique. Il n'est pas conçu pour une immersion continue dans l'eau.

Faites toujours attention à votre environnement lorsque vous utilisez l'application compagnon CAT TAILER pour trouver votre animal de compagnie. Ne vous laissez pas distraire lors de l'utilisation de l'application CAT TAILER et soyez attentifs aux obstacles imprévus et à la circulation des véhicules.

Garantie

CAT TAILER est couvert par une garantie d'une année complète à compter de la date d'achat. Pour en savoir plus allez sur cattailer.com/warranty.

Ambystoma Labs Inc. ne garantit pas que l'exploitation du produit sera ininterrompue ou sans erreur. Ambystoma Labs Inc. n'est pas responsable des dommages résultant du non-respect des instructions relatives à l'utilisation par Ambystoma Labs Products.

Limitation des dommages. SAUF DANS LA MESURE INTERDITE PAR LA LOI, AMBYSTOMA LABS INC. NE PEUT PAS ÊTRE TENUE RESPONSABLE DE TOUT DOMMAGE ACCESSOIRE, INDIRECT, SPÉCIAL, OU CONSÉCUTIF RESULTANT DE TOUTE VIOLATION D'UNE GARANTIE OU D'UNE CONDITION EXPRESSE OU IMPLICITE OU DE TOUTE AUTRE THÉORIE JURIDIQUE.